





- D** FireCom Kurzbedienungsanleitung
- GB** FireCom quick guide
- I** FireCom guida rapida

VFPOS Lobbyeinheit/Lobby unit/Unità piano di sbarco





G = grau/grey/grigio
 W = weiss/white/bianco
 R = rot/red/rosso
 Y = gelb/yellow/giallo
 GR = grün/green/verde
 B = schwarz/black/nero






ROCOM


VFPF Etageinheit/Floor unit/Unità piano



VFSMSA Maschineraumeinheit/Machine room unit/Unità sala macchine




OFF






ON

G = grau/grey/grigio
 W = weiss/white/bianco
 R = rot/red/rosso
 Y = gelb/yellow/giallo
 GR = grün/green/verde
 B = schwarz/black/nero

VFSMS Maschineraumeinheit mit SVG/ Machine room unit with PSU/ Unità sala macchine con alimentazione



G = grau/grey/grigio
 W = weiss/white/bianco
 R = rot/red/rosso
 Y = gelb/yellow/giallo
 GR = grün/green/verde
 B = schwarz/black/nero
 BL = blau/blue/blu



J6 ~~230V~~

J7

J8

OK


LED

D Erst Batterie dann Strom verbinden!

GB Connect frist battery then power!

I Collegare prima la batteria poi l'alimentazione!

VFCS/K Kabineneinheit/Car unit/Unità di cabina



Systemverkabelung/System cabling/cablaggio sistema

